

MAGNESE Office AC Charger f/Toshiba 65W

Order Reference: MA-101006

Product Information:

The MAGNESE® Office power adapter offers durable and portable laptop charging. This is the ideal replacement for laptop chargers, available for a wide range of laptop models and geographical regions.

Product Specification:

Related Power	65W
Suitable for	Toshiba
Input voltage	AC 100-240V
Laptop output voltage	DC 19V
Amps	3.42A
Tip Size	5.5mm*2.5mm – Pin inside



Further Information:

Order Reference	MA-101006
Protection	Short-circuit, over-voltage, over-current, temperature protection
Approvals	CE/RoHS
Packaging	Brown box with protective bubble bag
Package Contents	Magnese Office AC Charger for Toshiba 65W UK Power Cord (other regions on request)
Warranty	12 Months

At Magnese, we have built our reputation on responding to custom requests, please contact your Account Manager for further details and flexible minimum quantities.

About MAGNESE®

Our promise: *"Do everything we can to delight our customers every time, on time."*

Magnese technology accessories are built for the workplace. Using the best quality components to ensure our products withstand the challenges of the workplace, wherever that is.

Recognised as the safe choice of informed customers that want products that are fit for

Tel: +44 (0)1604 686252/686194 email: sales@magnese.com

Copyright of Magnese Ltd 2014
products@magnese.com

magnese
INSPIRED PROBLEM SOLVING



work. All our accessories are backed by a minimum of twelve months guarantee and compliant with manufacturer warranties.



MAGNESE Office Mains Charger f/Toshiba 65W

Compatible with the following:

- Toshiba Satellite A100 Series: FA100-151, A100-163, A100-188, A100-209, A100-259, A100-295, A100-500, A100-507, A100-508, A100-521, A100-522, A100-523, A100-525, A100-533, A100-570, A100-649, A100-S2211, A100-S2211TD, A100-S3211TD, A100-S8111, A100-S8111TD, A100-SP2022, A100-SP621, A100-ST2311, A100-ST3211
- Toshiba Satellite A105 Series: FA105, A105-S101, A105-S1012, A105-S1013, A105-S1014, A105-S101X, A105-S171, A105-S1712, A105-S171x, A105-S2001, A105-S2011, A105-S2021, A105-S2031, A105-S2051, A105-S2061, A105-S2071, A105-S2081, A105-S2091, A105-S2101, A105-S2111, A105-S2121, A105-S2131, A105-S2141, A105-S2194, A105-S2201, A105-S2204, A105-S2231, A105-S2236, A105-S271, A105-S2712, A105-S2713, A105-S2716, A105-S2717, A105-S2719, A105-S271X, A105-S361, A105-S3611, A105-S361X, A105-SP2012, A105-SP461
- Toshiba Satellite A110 Series: FA110-101, A110-177, A110-178, A110-203, A110-260, A110-289, A110-339, A110-370
- Toshiba Satellite A130 Series: FA130, A130-ST1311, A130-ST1313
- Toshiba Satellite A135 Series: FA135, A135-S2246, A135-S2256, A135-S2266, A135-S2276, A135-S2286, A135-S2296, A135-S2306, A135-S232, A135-S2346, A135-S2356, A135-S2376, A135-S2386, A135-S2396, A135-S4407, A135-S4417, A135-S4427, A135-S4437, A135-S4447, A135-S4457, A135-S4467, A135-S4477, A135-S4478, A135-S4487, A135-S4488, A135-S4499, A135-S4517, A135-S4527, A135-S4656, A135-S4677, A135-S4827, A135-SP4016, A135-SP4036, A135-SP4048, A135-SP4058, A135-SP4088, A135-SP4108, A135-SP4156
- Toshiba Satellite A200 Series: FA200-10W, A200-10X, A200-10Z, A200-11C, A200-12F, A200-13L, A200-130, A200-13R, A200-13T, A200-13U, A200-14D, A200-14E, A200-180, A200-18T, A200-19I, A200-19K, A200-19M, A200-1A9, A200-1AA, A200-1AB, A200-1AE, A200-1Ai, A200-1BP, A200-1BW, A200-1CC, A200-1CR, A200-1DA, A200-1DN, A200-1DQ, A200-1FJ, A200-1G6, A200-1GD, A200-1HU, A200-1M7, A200-ST2041, A200-ST2043
- Toshiba Satellite A205 Series: FA205, A205-S4537, A205-S4557, A205-S4567, A205-S4577, A205-S4578, A205-S4587, A205-S4597, A205-S4607, A205-S4617, A205-S4618, A205-S4629, A205-S4638, A205-S4639, A205-S4647, A205-S4707, A205-S4777, A205-S4797, A205-S7456, A205-SP4038, A205-SP4068
- Toshiba Satellite A100 Series: FA100-151, A100-163, A100-188, A100-209, A100-259, A100-295, A100-500, A100-507, A100-508, A100-521, A100-522, A100-523, A100-525, A100-533, A100-570, A100-649, A100-S2211, A100-S2211TD, A100-S3211TD, A100-S8111, A100-S8111TD, A100-SP2022, A100-SP621, A100-ST2311, A100-ST3211
- Toshiba Satellite A105 Series: FA105, A105-S101, A105-S1012, A105-S1013, A105-S1014, A105-S101X, A105-S171, A105-S1712, A105-S171x, A105-S2001, A105-S2011, A105-S2021, A105-S2031, A105-S2051, A105-S2061, A105-S2071, A105-S2081, A105-S2091, A105-S2101, A105-S2111, A105-S2121, A105-S2131, A105-S2141, A105-S2194, A105-S2201, A105-S2204, A105-S2231, A105-S2236, A105-S271, A105-S2712, A105-S2713, A105-S2716, A105-S2717, A105-S2719, A105-S271X, A105-S361, A105-S3611, A105-S361X, A105-SP2012, A105-SP461
- Toshiba Satellite A110 Series: FA110-101, A110-177, A110-178, A110-203, A110-260, A110-289, A110-339, A110-370
- Toshiba Satellite A130 Series: FA130, A130-ST1311, A130-ST1313
- Toshiba Satellite A135 Series: FA135, A135-S2246, A135-S2256, A135-S2266, A135-S2276, A135-S2286, A135-S2296, A135-S2306, A135-S232, A135-S2346, A135-S2356, A135-S2376, A135-S2386, A135-S2396, A135-S4407, A135-S4417, A135-S4427, A135-S4437, A135-S4447, A135-S4457, A135-S4467, A135-S4477, A135-S4478, A135-S4487, A135-S4488, A135-S4499, A135-S4517, A135-S4527, A135-S4656, A135-S4677, A135-S4827, A135-SP4016, A135-SP4036, A135-SP4048, A135-SP4058, A135-SP4088, A135-SP4108, A135-SP4156
- Toshiba Satellite A200 Series: FA200-10W, A200-10X, A200-10Z, A200-11C, A200-12F, A200-13L, A200-130, A200-13R, A200-13T, A200-13U, A200-14D, A200-14E, A200-180, A200-18T, A200-19I, A200-19K, A200-19M, A200-1A9, A200-1AA, A200-1AB, A200-1AE, A200-1Ai, A200-1BP, A200-1BW, A200-1CC, A200-1CR, A200-1DA, A200-1DN, A200-1DQ, A200-1FJ, A200-1G6, A200-1GD, A200-1HU, A200-1M7, A200-ST2041, A200-ST2043
- Toshiba Satellite A205 Series: FA205, A205-S4537, A205-S4557, A205-S4567, A205-S4577, A205-S4578, A205-S4587, A205-S4597, A205-S4607, A205-S4617, A205-S4618, A205-S4629, A205-S4638, A205-S4639, A205-S4647, A205-S4707, A205-S4777, A205-S4797, A205-S7456, A205-SP4038, A205-SP4068
- Toshiba Satellite M35X Series: FM35X, M35X-114, M35X-149, M35X-S109, M35X-S111, M35X-S114, M35X-S1141, M35X-S1142, M35X-S1143, M35X-S149, M35X-S1491, M35X-S1492, M35X-S161, M35X-S1611, M35X-S163, M35X-S1631, M35X-S309, M35X-S3091, M35X-S311, M35X-S3111, M35X-S3112, M35X-S329, M35X-S3291, M35X-S349, M35X-S3491, M35X-SP111, M35X-SP114, M35X-SP161, M35X-SP171, M35X-SP181, M35X-SP311, M35X-SP349
- Toshiba Satellite M40 M45 Series: FM40-S312TD, M45-S165, M45-S1651, M45-S165X, M45-S169, M45-S1691
- Toshiba Satellite M55 Series: FM55-S1001, M55-S139, M55-S1391, M55-S139X, M55-S141
- Toshiba Satellite M60 M65 Series: FM60-S811, M60-S8112, M60-S9093, M65-S809, M65-S8091, M65-S8092, M65-S821, M65-S8211, M65-S9062, M65-S9063, M65-S9064, M65-S9065, M65-S909, M65-S9091, M65-S9092, M65-SP811, M65-SP959



MAGNESE Office Mains Charger for Toshiba 65W

- Toshiba Satellite P205 Series: FP205D-S7429, P205D-S7438, P205D-S7439, P205D-S7454, P205-S6237, P205-S6247, P205-S6257, P205-S6267, P205-S6287, P205-S6297, P205-S6298, P205-S6307, P205-S6337, P205-S6347, P205-S6348, P205-S7469, P205-S7476
- Toshiba Satellite U305 Series: FU305, U305-S5077, U305-S5087, U305-S5097, U305-S5107, U305-S5117, U305-S5127, U305-S7432, U305-S7446, U305-S7448, U305-S7467, U305-S7477, U305-SP5017, U305-SP5028, U305-SP5037
- Toshiba Tecra L2 Series: FL2-S011, L2-S022
- Toshiba Satellite 1000 1100 1130 1200 Series: F1000-S157, 1000-S158, 1005-S157, 1005-S158, 1100-S101, 1110-S153, 1110-SP153, 1115-S103, 1115-S107, 1115-S123, 1115-SP153, 1130-S155, 1130-S156, 1135-S125, 1135-S155, 1135-S1551, 1135-S1552, 1135-S1553, 1135-S1554, 1135-S156, 1200-S121, 1200-S122
- Toshiba Satellite 1600 1700 Series: F1605CDS, 1625CDT, 1675CDS, 1695CDT, 1715XCDS, 1730-S101, 1735-S101, 1750-S202, 1755-S202
- Toshiba Satellite 3000 Series: F3000-S304, 3000-S307, 3000-S353, 3005-S303, 3005-S304, 3005-S307, 3005-S308, 3005-S403
- GATEWAY Solo: FSolo1100, Solo1150, Solo1200, Solo1400, Solo1450, Solo2100, Solo2150, Solo2200, Solo2300, Solo2350, Solo2500, Solo2550, Solo3100, Solo3150, Solo400S, Solo450, Solo5100, Solo5150, Solo5300, Solo5350, Solo600, Solo9100, Solo9150, Solo9300, Solo9500, Solo9550
- GATEWAY E Series: FE-100M, E-100M-G, E-100M-SB, E-155C, E-155C-G, E-265M, E-265M-G, E-475M, E-475M-G
- GATEWAY 3000 Series: F3000, 3018, 3040, 3500, 3520, 3522, 3525, 3545, 3550, 3610, 3018GZ, 3040GZ, 3100-Fireant, 3100SE-Fireant, 3100SL-Fireant, 3100XL-Fireant, 3150, 3150S, 3520GZ, 3522GZ, 3525GB, 3545GZ, 3550GH, 3550GZ, 3610GZ, 3610GZ
- GATEWAY 4000 series: F4000, 4010, 4012, 4014, 4016, 4024, 4025, 4026, 4028, 4030, 4520, 4525, 4528, 4530, 4532, 4534, 4535, 4538, 4540, 4541, 4542, 4543, 400VTX, 4012GZ, 4014GB, 4024GZ, 4025GZ, 4026GZ, 4028GZ, 4028JP, 4030GH, 4030GZ, 4520GZ, 4525GZ, 4528MX, 4530GH, 4530GZ, 4535GX, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 4541BZ, 4542GP, 4543BZ
- GATEWAY 6000 series: F6000, 6010, 6018, 6020, 6021, 6022, 6023, 6510, 6518, 6520, 6525, 6530, 6531, 6010GZ, 6018GH, 6018GX, 6018GZ, 6020GZ, 6021GH, 6021GZ, 6022GZ, 6023GP, 6510GZ, 6518GZ, 6520GZ, 6525GP, 6531GZ, 6834MX
- GATEWAY CX series: FC120X, CX200, CX200S, CX200X, CX210, CX210X, CX2608, CX2610, CX2615, CX2618, CX2619, CX2620, CX2720, CX2726, CX2728
- GATEWAY M series: FM1200, M1300, M210S, M210X, M210XL, M250A, M250B, M250E, M250ES, M250G, M250GS, M255E, M255E-SB, M275, M275R, M275X, M275XL, M280, M280E, M285E, M285E-SB, M305CRV, M320, M320S, M320X, M320XL, M360A, M360B, M360C, M405, M460B, M460QS, M505, M505X
- GATEWAY MT series: FMT3418, MT3707, MT3707b, MT6224j, MT6225j, MT6704, MT6704h, MT6705, MT6706, MT6707, MT6708, MT6709, MT6709h, MT6821, MT6828, MT6828h, MT6830, MT6831, MT6832b, MT6833b, MT6834b, MT6835j, MT6839b
- GATEWAY MX series: FMX1023, MX1023h, MX1025, MX1026, MX1027, MX3042, MX3044, MX3044h, MX3103b, MX3142m, MX3210, MX3212, MX3215, MX3228, MX3231, MX3410, MX3410h, MX3412, MX3412h, MX3414, MX3416, MX3417, MX3558, MX3558h, MX3560, MX3560h, MX3562, MX3563, MX3563h, MX3610, MX3701, MX3702, MX6025, MX6025h, MX6027, MX6027h, MX6028, MX6030, MX6121, MX6123, MX6124, MX6124h, MX6128, MX6131, MX6135, MX6211b, MX6214, MX6215b, MX6216, MX6420, MX6421, MX6423, MX6424, MX6425, MX6426, MX6427, MX6428, MX6430, MX6433, MX6436, MX6437, MX6438, MX6439, MX6440, MX6442, MX6445, MX6446, MX6447, MX6450, MX6455, MX6625, MX6627, MX6627h, MX6629, MX6629h, MX6631, MX6633, MX6633h, MX6641, MX6650, MX6650h, MX6912, MX6919, MX6921b, MX6922b, MX6923b, MX6926b, MX6927, MX6928, MX6930, MX6931, MX6951, MX6955, MX6956, MX6957, MX6958, MX6959, MX6960, MX6961, MX6961h, MX7337, MX7337h, MX7340, MX7520h, MX8520, MX8710, MX8711, MX8715, MX8734, MX8736j
- GATEWAY NX series: FNX100X, NX200S, NX200X, NX250X, NX260X, NX270S, NX500S, NX500X, NX550X, NX550XL, NX850X, NX850XL, NX860, NX860S, NX860X, NX860XL
- GATEWAY S series: FS-7125C, S-7200, S-7200C, S-7200C, S-7200N, S-7200N, S-7210M, S-7500, S-7500N, S-7500N, S-7510N, S-7700N, S-7710N
- ACER Travel-Mate and Aspire Notebooks: TM211T, 212T, 213TX, TM340T, TM 341T, TM342, TM345T, TM347T, TM351TE, TM350TE, TM352TE, TM352TE-N, TM353TE, TM353TEV, TM354TE, TM354TEV, TM521TE, TM524TXV, TM525TE, TM525TXV, TM528TE, TM551XV, TM600TER, TM602TER, TM603TER, TM604TER, TM 610TXV, TM610TXVi, TM610TXX, TM611TXV, TM611TXX, TM612TXV, TM612TXX, TM613TXV, TM613TXX, TM730TX, TM732TX, TM734TL, TM735TLV, TM738TLV, TM739TLV, 1680(1681LCi, 1681WLCi, 1681WLMi, 1683WLMi, 1684WLMi, 1685WLMi), 2010, 2020, 3502WLC, 3502WLCi, 3502WLMi, 3603WXCi, 3603WXM, 3602NWXMi, 3603WXCi 3603WXM, 3603NWXMi, 3603XCi, 3608NWXMi, 3608WXCi 3608WXM, 5002LMi, 5002WLMi, 5004WLMi



- Acer Aspire: 1200, 1410 (1414WLCi), 1640 (1642WLMi), 1650, 1690 (AS1690LCi, AS1690WLCi, AS1690WLMi, AS1691WLCi, AS1691WLMi, AS1692WLMi, AS1694WLMi), 3000 (3002LCi, 3002WLCi, 3002WLMi, 3003WCi, 3003WLCi), 3030, 3500 (3502LCi, 3502NLCi, 3503LCi, 3503WLCi, ZL6), 3600 (3603NWXM), 3610, 5002LM, 5002LMi, 5002WLCi, 5030, 5510, 9100

- Acer Travel-Mate: 2350, 2400, 2410, 3000, (3002WTCi), 3210 (3213WXCi, 3213WXM), 3220 (3220WXCi, 3220WXM), 3222WXCi, 3222WXM), 3230, 4020, 4050 (4052LCi), 4060, 4100 (4100LCi, 4100LMi), 4150, 8100 (8104WLMi, ZF1), 2300, 2700, 290, 290E, 3200, 4000, 4500, 6000, 8000
- Acer Travel-Mate 200 Series: 200DX, 200T, 201, 201T, 202, 202T, 210, 210T, 210TER, 210TXF, 211, 211T, 212, 212T, 212TE, 212TXV, 213, 213T, 213TXV, 222X, 223X, 223XC, 223XV, 225X, 225XC, 225XV, 230XC, 230XV, 230XV-PRO, 233LC, 233X, 233XV, 233XVi, 234LCi, 261XC, 261XV, 260, 261, 261X, 261XC, 261XV, 270XV, 272LC, 272X, 272XV, 272XVi, 273X, 273XV, 275LC, 281XC, 281XV, 283LC, 283LCi, 283XV, 283XVi, 290LC, 290LCi, 290LMi, 290XCi, 290Xi, 290XMi, 290XVi, 291LCi, 291LCi-G, 291LMi, 291LMi-G, 291XCi, 291XCiH, 292LC, 292LCi, 292LM, 292LMi, 293LCi, 293LMi.
- Acer Travel-Mate 300 Series: 310, 311, 312, 313, 314, 310T, 311T, 312T, 313T, 314T, 320, 330T, 332T, 333T, 341TV, 342T, 343TV, 345, 347, 345T, 347T, 350TE, 350TE-N, 351TE, 351TEV, 352TE, 353TE, 353TEV, 354TE, 354TEV, 361EVi, 364ECi, 365, 371LCi, 371LMi, 371TCi, 371TCi XP, 371Ti, 371Tmi, 371LCi, 371LMi, 371TCi, 371TCi XP, 371Ti, 371Tmi
- Acer Travel-Mate 500 Series: 512DX, 512T, 512TE, 512T-64, 513DX, 513T, 514T, 514TXV, 515TE, 516TE, 517TE, 530LC, 530LCi, 530XC, 530XCi, 530XV, 530XVi, 531LC, 531LCi, 531XC, 531XCi, 531XV, 531XVi, 533LC, 533LCi, 533XC, 533XCi, 533XV, 533XVi, 534LC, 534LCi, 534TL, 534XC, 534XCi, 534XV, 535LC, 535LCi, 536LCi, 540LCi, 540LMi, 541LC, 541LCi, 541LCib, 541LMi, 541XCi, 541XV, 542LCi, 542LMi, 543LCi, 543LMi
- Acer Travel-Mate 600 to 663 Series: 600, 602, 603, 604, 610, 611, 612, 613, 614, 610TXC, 610TXV, 610TXVi, 611TXC, 611TXCi, 611TXV, 612TXC, 612TXCi, 612TXV, 613TXC, 613TXV, 614TXVCi, 620, 621, 623, 621LV, 621XC, 621XV, 623LC, 623LCi, 630, 632, 633, 630XV, 630XCi, 632XCi, 633LCi, 650LC, 650XC, 650XCi, 653LC, 653LCi, 653XC, 653XCi, 653XV, 654LC, 654LCi, 654XC, 654XCi, 654XV, 655LCi, 660LCi, 660LMi, 661LC, 661LCi, 661LM, 661LMi, 661XC, 661XCi, 661XVi, 662LC, 662LCi, 662LM, 662LMi, 662XCi, 663LCi, 663LM, 663LMi
- Acer Travel-Mate 720 to 740 Series: 720, 722, 723, 720TX, 720TXV, 721TX, 722iTX, 722iTXV, 722TX, 723TX, 723TXV, 730, 732, 734, 735, 730TX, 730TXV, 732TLV, 732TX, 732TXV, 734TL, 734TXV, 735TLV, 736, 737, 738, 739, 736TL, 736TLV, 737TLV, 738TLV, 739GTLV, 739TLV, 740, 741, 744, 740LVF, 741LVF, 744LCF
- Acer Travel-Mate 800 Series: 800LC, 800LCi, 800LCib, 800LMi, 800LMib, 800XC, 800XCi, 801LC, 801LCi, 801LCib, 801LMi, 801LMib, 801XC, 801XCi, 801XVi, 802LCi, 802LCib, 802LMi, 802LMib, 802XCi, 803LC, 803LCi, 803LCib, 803LM, 803LMi, 803LMib, 803XCi, 803XVi, 804LC, 804LCi, 804LCib, 804LM, 804LMi, 804LMib